



Shipping and Mailing Software Compatibility Chart

78XX Models = 7815,7820,7820R,7885,7880,7840,7824

76XX Model = 7620, 7680

COMPANY NAME	SHIPPING/MAILING SOFTWARE	NCI MODELS SUPPORTED	PROTOCOL REQUIREMENTS
Abol Software	Abol Express	78XX	NCI
Computer Ventures	CargoWare (Shipmaster)	78XX	NCI
F.C. Rock & Associates	SMS	78XX and 76XX	NCI
Fascor	Logistics Management Software. SC.E Commerce TMC	78XX	NCI
Federal Express	PowerShip	78XX and 76XX	NCI
Federal Express	Café	78XX	8213
Harvey Software	Computerized Parcel System	78XX	NCI,3835, 3825 or 8213
Kewill E Commerce/Aristo	APSS	78XX and 76XX	NCI
Kewill E Commerce/Aristo	Clippership	78XX and 76XX	NCI
Kewill E Commerce/Aristo	Kewil.ship	78XX and 76XX	NCI
Malvern Computers		78XX	3835,3825 or NCI
Manhattan Associates	PKMS	78XX with POSH Wedge	Autoprint
PC Synergy	PostalMate	76XX	AS350D and PS6L
Pfastship World Logistics	PfastShip 2000	78XX with Welch Allyn Wedge and 76XX	8213
Pick Professionals	Outbound Shipping	78XX and 76XX	NCI
Pitney Bowes	PB TMS	78XX, except 7815	8213
QuickShip (AKA: Acctronix)	Compass	78XX	NCI
ScanData	SmartPac	78XX and 76XX	NCI, AS350D, 8213
ShipRite Software	ShipRite	76XX	NCI
Stat Supply Company	EasyShip	78XX	NCI
TanData Corporation	Prologistics CS (Parcel Manifest System- PMS)	78XX	NCI
UPS	Worldship	78XX	3835 or 3825 (4800B, Even Parity)
Varsity Logistics	VarsityShipper	78XX and 76XX	NCI
Vtechnologies	StarShip	78XX, except 7815	8213 or 3835
Windowbook	Postal Package Partner, Postal Business Companion	7623, 76XX	NCI

What is Protocol?

- 1) Protocol is the format in which the string of data sent to the PC or host device from the scale.
- 2) Each scale manufacturer has there own distinct format in which data is sent.
- 3) The application software within each scale includes other scale manufacturers and older NCI products.
- 4) The standard default setting is NCI protocol, you can change the protocol of each scale, by simply entering into the diagnostics configuration via the keyboard.
- 5) Use this feature when replacing Older NCI products or competitors scales in the field, or to connect to a shipping or mailing software that is used by the customer.

Protocols Available

Model	Protocol Available
7815	NCI, NCI 3825
7820, 7820R, 7885, 7880, 7829, 7824, 7840	NCI 78XX, Toledo 8213, NCI 3835, SMA, Auto Send 1 & 2, Print*
7620, 7680	NCI 76XX, SMA, Detecto AS350D, Toledo PS6L



A division of Weigh-Tronix, Inc.
1000 Armstrong Drive
Fairmont, MN 56031 USA
Telephone: 507-238-4461
Facsimile: 507-238-4195
www.wt-nci.com

Weighing Solutions for Mailing & Shipping Operations