

B240

Counting Scale with Built-in Database



- **Usability**– Ideal for parts counting or any busy receiving/shipping, warehouse or assembly areas where inventory control is essential
- **Built-in Database**– Holds up to 1000 stored part numbers, piece weights, and inventory stock levels
- **Capacity**– 15 lb / 7 kg, 30 lb / 15 kg and 60 lb / 30 kg
- **Accuracy**– 30,000 displayed divisions
- **Display**– Large, easy-to-read color touch screen display to provide the operator with all essential data when counting
- **Power**– AC adapter with built-in rechargeable battery with up to four hours battery life between charges
- **Construction**– ABS plastic housing with stainless steel weight platter
- **Platform Dimensions**– 9" x 12" / 230 mm x 305 mm

B240 Counting Scale with Built-in Database

Features

The B240 Counting Scale is ideal for use in any busy receiving/shipping, warehouse or assembly areas.

Mainly designed for counting, the B240 provides an easy-to-use sampling process to deliver highly accurate sampling, along with a built-in database for fast recall of already stored piece weights and other part number data.

The B240 offers a range of fast sampling routines to meet most operators' requirements. Sampling routines like auto piece weight updates, which allows you to keep adding parts to a sample to build up a more accurate piece weight.

Display: The color touch screen provides the operator with an array of useful data to best help them carry out their role

Database: The B240 comes with a built-in database for holding a wide range of stored data from customer address data to around 1000 PLU's for storing part numbers, descriptions, piece weights, tare weights, part quantities on hand, and upper and lower accept check count points

Check Counting: Designed for speed and efficiency, the B240 is ideal for applications where parts are regularly packed to standard box quantities. The color touch screen display provides the operator with a fast and easy visual to indicate when the correct quantity of parts is in the accept range. By tapping the screen, the display is maximized for even better visibility.

Accumulation: The B240 has the ability to easily accumulate counted parts to give a running total, which is ideal when large quantities of parts are being counted

The base is constructed of ABS plastic, which provides outstanding protection for daily weight usage and is fitted with a removable stainless steel pan.

AC and battery powered, the B240 comes standard with an internal rechargeable lead acid battery that will provide around four hours of battery life - ideal for areas where power outlets are limited.



a division of Avery Weigh-Tronix, LLC

Brecknell

1000 Armstrong Dr., Fairmont, MN 56031
Toll free: 800-637-0529, Tel: 507-238-8702
Fax: 507-238-8271
e-mail: sales@brecknellcales.com
www.brecknellcales.com



Brecknell

Foundry Lane, Smethwick
West Midlands B66 2LP UK
Tel: +44 (0) 845 246 6717
Fax: +44 (0) 845 246 6718
Email: sales@brecknellcales.co.uk
www.brecknellcales.co.uk



Specifications

Capacities:

15 lb x 0.0005 lb / 7 kg x 0.0002 kg

30 lb x 0.001 lb / 15 kg x 0.0005 kg

60 lb x 0.002 lb / 30 kg x 0.0001 kg

Unit: lb, kg, g

Display: 7" color graphic touch screen display with 800 x 480 resolution

Database: 1000 PLU's

Power: AC adapter and built-in rechargeable battery

Battery Life: Four hours between recharges

Communication Ports: Two USB 2.0, two RS-232 and one Ethernet socket are standard

Operating Temperature:

32° F to 104° F / 0° C to 40° C

Scale Features: Counting, check weighing, customer ID, PLU, and inventory control database with accumulator and operator ID

Scale Dimension (L x W x H):

14.9" x 13" x 5.2" / 378 mm x 330 mm x 132 mm

Platform Dimension (L x W):

9" x 12" / 230 mm x 305 mm

Product Weight: 8 lb / 3.6 kg

Packaging Dimension (L x W x H):

7.5" x 13.2" x 14.4" / 430 mm x 370 mm x 190 mm

Shipping Weight: 9.7 lb / 4.6 kg

