

GF-3

Wire Grips

Grooved snubber and post design ensures center break of flexible wire up to 1.6 mm (0.06 in) diameter. May also be used for testing cord, rubber or filaments. 25 mm (0.98 in) diameter snubber is mounted on swiveling plate so that the specimen will align with the force when load is applied. A ball socket mounting screw in upper grip helps ensure proper alignment with lower grip.

Capacity

1 kN, 225 lbf

Packaging

Includes upper and lower grip.



Note: The GF-3 is supplied with the following adapters for mounting to some force gauges, loadcells and test stands.

	<i>Part Number</i>
<i>Coupling, 1/4-20F x 5/16-18F</i>	<i>17056</i>
<i>Coupling, 1/4-20F x #10-32F</i>	<i>17057</i>
<i>Adapter, 1/4-28 x 3/8-16</i>	<i>21046-1</i>
<i>Adapter, #10-32 x 3/8-16</i>	<i>21046-2</i>

See pages 93-113 for additional adapters required.

Ordering Information

Model	Part No.	Description
GF-3	GF-3	Wire Grip - 1 kN (225 lbf)