SS6600 MAX-LT Floor Scale



MAXIMUM PROTECTION.

MAXIMUM EASY TO CLEAN.

MAXIMUM DURABILITY.

There's never been a greater need to protect your products and customers from deadly pathogens searching for a hard-to-access and clean place to grow. And until now, there's never been a better floor scale to ensure a safer, more sanitary production environment. The new SS6600 MAX-LT floor scale provides the maximum washdown protection with an easy-to-clean structure. Because it's so easy to sanitize, you can be confident that the SS6000 MAX-LT's base is safe, hygienic and ready to assist you in maintaining high standards of sanitation and to pass a government agency or third-party safety audit.





Maximum washdown protection

All-304SS construction extends to the diamond-plate deck, frame, welded-seal IP69K load cells, leveling feet and hardware, making the SS6600 MAX-LT ideal for high-pressure, high-temperature and caustic-cleaning chemical washdown, day in and day out.

Maximum cleanability

An innovative lift-top deckplate with gasstrut assist allows full access to the solid-bar frame with continuous welds for an extremely sanitary design. No open tubes, crevices or limited-access areas mean pathogens have nowhere to establish a foothold and contaminate your product.

Maximum durability

The 304SS heavy-duty deckplate, structural frame load cells and hardware are designed to survive and thrive in the most challenging real-world manufacturing environments. You can depend on the SS6600 XLT floor scale to provide superior weighing performance for the long run.



APPLICATIONS

- · Meat, poultry and seafood processing
- · Chemicals, solvents and acids
- · Food processing and manufacturing
- Pharmaceuticals, supplements and nutraceuticals
- Aerospace, defense contractors and munitions
- Paper, printing, ink and paint manufacturing
- · All sanitary washdown process industries



- Pair with an outstanding Pennsylvania Scale Digital Weight Indicator
- 7600/4 WD, IP66K High Pressure Washdown Protection, 304 Stainless Steel Enclosure and Hardware. Full numeric and multifunction keyboard including Zero, Tare, Keypad Tare, Gross



Net, Print/Data Output, Units and setpoint value entry functions

 7400 WD, IP66K High Pressure Washdown Protection, 304 Stainless Steel Enclosure and Hardware. Simple operation with Zero, Tare, Gross/Net, Units and Print/Data Output functions.



 Contact Pennsylvania Scale to discuss your application requirements so we can recommend the best standard or custom design system for you.

Available Sizes		
Model Number	Dimensions	Capacity
SS6600-3636-1K MAX-LT	36" X 36"	1,000 lbs.
SS6600-3636-2K MAX-LT	36" X 36"	2,000 lbs.
SS6600-3636-5K MAX-LT	36" X 36"	5,000 lbs.
SS6600-4848-1K MAX-LT	48" X 48"	1,000 lbs.
SS6600-4848-2K MAX-LT	48" X 48"	2,000 lbs.
SS6600-4848-5K MAX-LT	48" X 48"	5,000 lbs.
SS6600-4848-10K MAX-LT	48" X 48"	10,000 lbs.
SS6600-6060-5K MAX-LT	60" X 60"	5,000 lbs.
SS6600-6060-10K MAX-LT	60" X 60"	10,000 lbs.

MADE IN THE USA

Manufactured in our plant in Lancaster, PA plant providing some of the fastest lead times in the industry!



